

Installation Instructions

1288000A

Curb Stop / Swing Check Valve Assembly

1-1/4", 1-1/2", 2" SS Curb Stop/Swing Check Valve FNPT

⚠ WARNING ⚠ **INSTALLATION SHALL BE PERFORMED BY QUALIFIED PERSONNEL ONLY**

Installation Procedure:

1. Verify correct orientation of the curb stop/swing check valve assembly. Confirm direction of flow as marked on the valve body and the orientation of the stop handle.
2. Make NPT connections using two wraps of PTFE thread seal tape and/or use PTFE paste (*do not use petroleum based paste*).
3. Tighten fittings using a properly sized wrench or strap wrench.
4. Refer to the installation instructions for the connection kits to complete any compression connections to various pipe or tubing.

